

Drill Blade Installation Instructions



1. The picture above shows the front and bevel side of the Blade rotating in the correct direction.

2. The flat side faces inward towards hub and bevel side faces outward towards the Depth wheel.



The picture to the left is showing the blade installed the incorrect way. The bevel should be outwards towards the depth wheel.



Bevel Side - Outside



Flat Side - Inside